




**REPROGRAMMING THE**

**ROWE ELECTRONICS**

**WIRELESS CONTROL SYSTEM**

## REPROGRAMMING THE ROWE ELECTRONICS WIRELESS CONTROL SYSTEM



Hold a magnet over the "L" inside the circle  symbol, until the LED lights in the dot.

The LED will stay lit for 20 seconds.



Within that time frame,  
press and hold one of the arrow buttons  
on the Remote Control Fob,  
until the LED blinks.

The Wireless Control System is now reset.